

Phones

How to clear Missed Messages

To clear your missed messages:

Press the "down" button on the directional pad on the right side of your phone. This is the shortcut for bringing up the missed calls screen. Viewing the screen is the only requirement to clear the indicator.

Press the home button twice to get back the the home screen after looking to see who called.

Unique solution ID: #1366

Author: n/a

Last update: 2014-10-10 23:56